AOC

AS110DX
AS110DX/86
Ergonomic Monitor Arm



Monitor Size: 13"~32"
Weight Capacity: 2~9 kg
VESA Size: 75x75 mm, 100x100 mm

User Manual

A. Clamp-Mounting
B. Hole-Mounting
C. Cable-Management
D. VESA Mount Installation
E. Monitor Angle Adjustment

Packaging List



A. Clamp-Mounting Procedures





Diagram of full-assembled monitor arm specs in depth



B. Hole-Mounting Procedure



Diagram of full-assembled monitor arm specs in depth



C. Cable Management



D. VESA Mount Installation

Step **1**

VESA:75x75mm,100x100mm



Step **2**



Monitor Weight Adjustment

"+" Increase weight capacity
"–" Decrease weight capacity



Note: Please ensure monitor is within the 2~9kg weight range.

Condition 1: After attached, your monitor is freely movable in any direction without adjustment.
Condition 2: After attached, monitor will bounce up, please use the wrench provided to turn "-" counterclockwise until stable.
Condition 3: After attached, monitor will fall down, please use the wrench provided to turn "+" clockwise until stable.

E. Adjust Monitor Angles





Envision Peripherals Inc.
490 North McCarthy Blvd. Suite #120 Milpitas, CA 95035

AOC International (Europe) B.V.
Prins Bernhardplein 200, 1097 JB Amsterdam, The Netherlands

www.aoc.com

Made in China

AFTER INSTALLATION, ADJUST
GAS-SPRING POWER

Warning

1. Ensure monitor is tightened to monitor arm
2. Ensure monitor is not over-weight (2~9kg)

Weight Adjustment

Reduce Arm
Weight Capacity

Increase Arm
Weight Capacity

Warning

Q&A

1) Why monitor arm is hard to press down?
It is normal to feel pressure while pressing down without a monitor. Once the monitor is mounted, the weight of itself helps to reduce the air-pressure, then the arm will be easy to press down.
2) Why my monitor cannot move lower or higher freely?
Please adjust the "+" or "-" for best experience. Please do check your monitor weight, if > 9kg, arm will not hold.
3) Why my Type-C does not charge?
Each Type-C cable has different materials and please reverse the cable to try again.