





Dell Premier Rechargeable Wireless Mouse MS7421W


Quick Start Guide




<http://www.dell.com/support/MS741W>




1




2




2




3





3




3





www.dell.com/support/dpem





2




3



3



www.dell.com/support
www.dell.com/regulatory_compliance



© 2020-2022 Dell Inc. or its subsidiaries.
2022-07



0TW0G4A01