Jabra Evolve2 Buds







Jabra GN





Say hello to a more sustainable product

IT products are associated with a wide range of sustainability risks throughout their life cycle. Human rights violations are common in the factories. Harmful substances are used both in products and their manufacture. Products can often have a short lifespan because of poor ergonomics, low quality and when they are not able to be repaired or upgraded.

This product is a better choice. It meets all the criteria in TCO Certified, the world's most comprehensive sustainability certification for IT products. Thank you for making a responsible product choice, that help drive progress towards a more sustainable future!

Criteria in TCO Certified have a life-cycle perspective and balance environmental and social responsibility. Conformity is verified by independent and approved verifiers that specialize in IT products, social responsibility or other sustainability issues. Verification is done both before and after the certificate is issued, covering the entire validity period. The process also includes ensuring that corrective actions are implemented in all cases of factory non-conformities. And last but not least, to make sure that the certification and independent verification is accurate, both TCO Certified and the verifiers are reviewed regularly.

Want to know more?

Read information about TCO Certified, full criteria documents, news and updates at **tocertified.com**. On the website you'll also find our Product Finder, which presents a complete, searchable listing of certified products.

© 2022 GN Audio A/S. All rights reserved. Jabra® is a trademark of GN Audio A/S. The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by GN Audio A/S is under license.

Made in China MODEL: OTE140R / OTE140L / CPB145



1.	Welcome7		
2.	Jabra Evolve2 Buds overview8		
3.	. How to wear1		
	3.1	Changing EarGels	
4.	Но	w to charge12	
	4.1	Charging the earbuds	
	4.2	Fast charge the earbuds	
	4.3	Charging the charging case using USB	
	4.4	Charging the charging case using the Jabra wireless charging pad	
5.	What the LEDs mean16		
6.	6. How to connect		
	6.1	Connecting with a computer	
	6.2	Pairing with a mobile device	
7.	Но	w to use21	
	7.1	Power the earbuds off/on	
	7.2	Music controls for Microsoft Teams earbuds	
	7.3	Call controls for Microsoft Teams earbuds	
	7.4	Microsoft Teams controls for Microsoft Teams earbuds	
	7.5	HearThrough, ANC, and Voice assistant controls for Microsoft Teams earbuds	
	7.6	Music controls for UC earbuds	
	7.7	Call controls for UC earbuds	

	7.8	HearThrough and ANC controls for UC earbuds
	7.9	Adjustable Active Noise Cancellation (ANC)
	7.10	HearThrough
	7.11	Sidetone
	7.12	Single earbud use for Microsoft Teams earbuds
	7.13	Single earbud use for UC earbuds
	7.14	Auto-pause music
	7.15	Auto-mute microphone during calls
	7.16	Sleep mode
	7.17	MyControls
	7.18	Multipoint and multiple call handling
	7.19	Voice assistant
	7.20	Voice guidance and languages
	7.21	Firmware updates
	7.22	Reset the earbuds
8.	Sof	tware44
	8.1	Jabra Direct
	8.2	Jabra Sound+
9.	Sup	pport46

- 9.1 FAQ
- 9.2 How to care for your earbuds
- 9.3 Replacement accessories
- 9.4 Using replacement earbuds
- 9.5 Using a replacement charging case
- 9.6 Using a replacement Jabra Link 380

1. Welcome


Thank you for using the Jabra Evolve2 Buds. We hope you will enjoy it!

Jabra Evolve2 Buds features


- · Certified for leading virtual meeting platforms
- Certified for Microsoft Teams
- Jabra MultiSensor Voice[™] for professional calls on the go
- USB adapter enhances sound & connection
- Ultra-compact design for maximum comfort
- Up to 8 hours battery, 33 with the case & fast charge
- Active Noise Cancellation (ANC)

2. Jabra Evolve2 Buds overview

Farbuds



Wireless charging case




Jabra Link 380 Bluetooth adapter



USB-A to USB-C charging adapter




FarGels




Wireless charging pad (not supplied with all variants)



USB-A charging cable



3. How to wear




Insert each earbud into your ear and ensure the microphones are pointed towards your mouth The fit should feel light and comfortable. You may need a different size EarGel for each ear.

If your voice cannot be heard clearly when on a call, please ensure the microphones are pointing towards your mouth.

3.1 Changing EarGels

For the optimal audio and ANC experience, it is recommended to take the MyFit test in Jabra Sound+ to ensure you have the best fit. If you don't have a good fit, try a different eargel size. The medium EarGels are pre-mounted on the earbuds.




4. How to charge

Get up to 5 hours of talk time and 8 hours of music on a single charge with ANC on, with a total of up to 33 hours of music with the charging case.

4.1 Charging the earbuds

Place the earbuds in the charging case and close the lid. It takes up to 2 hours to fully recharge the earbuds.

When the charging case is opened, the LEDs on the earbuds will light up green, yellow or red, to indicate the battery status of the earbuds. The LED on the front of the charging case indicates the battery status of the charging case.



4.2 Fast charge the earbuds

When the earbuds are at low battery, placing them in the charging case for 5 minutes will fast charge the earbuds and give up to 1 hour of music playback. Fast charging the earbuds requires that the charging case has a minimum of 30% battery.

You can see the current battery status of the earbuds and charging case in Jabra Sound+.

4.3 Charging the charging case using USB

It takes up to 2 hours to fully charge the earbuds and the charging case using a USB-C charging cable.




The charging case uses the standard USB voltage of 5V +- 0.25V. It is not recommended to charge the earbuds using a power supply with a higher voltage.

4.4 Charging the charging case using the Jabra wireless charging pad

The charging case is Qi-certified. Place the charging case in the center of the Jabra wireless charging pad. The LED on the charging case will flash to indicate the charging case is placed correctly. It takes up to 4 hours to fully charge the earbuds and the charging case.



5. What the LEDs mean



EARBUD STATUS

- High battery
- Medium battery
- Low battery







Pairing

Resetting



BATTERY STATUS WHEN OPENING CHARGING CASE

- High battery
- Medium battery
- Low battery
 - Critically low battery (earbuds not charging)



CHARGING CASE STATUS WITH USB CABLE



Medium battery Low battery

Fully charged




Firmware update error (see Section 7.20)



CHARGING CASE STATUS WITH WIRELESS CHARGING PAD







Note: When fully charged, the LEDs on the charging case and wireless charging pad will turn off.







JABRA LINK 380 STATUS



Headset connected

Active call

Listening to music

Microphone muted

 Connected to Microsoft Teams*

Microsoft Teams notification*

^{*}Microsoft Teams earbuds only

6. How to connect


6.1 Connecting with a computer

Plug the supplied Jabra Link 380 Bluetooth adapter into a USB port on your computer. The Jabra Evolve2 Buds and the Jabra Link 380 are pre-paired and ready for use out of the box. The Bluetooth range is up to 20 meters or 65 feet.




To hear audio in the headset, you may need to select the Jabra Link 380 as the playback device in the audio settings for your operating system and video conferencing application.

6.2 Pairing with a mobile device



- Power on the earbuds by removing them from the charging case. Alternatively, press the **Left** and **Right** buttons simultaneously to power the earbuds on.
- Press and hold (3 sec) the Left and Right buttons simultaneously until the earbud LEDs flash blue. The earbuds will now be ready to pair with your mobile device.
- Wear the earbuds and follow the voiceguided pairing instructions to pair with your mobile device.


7. How to use



7.1 Power the earbuds off/on

To power on the earbuds, remove them from the charging case.

To power off the earbuds, place them in the charging case.



Alternatively, the earbuds can be manually powered off by pressing the **Left** and **Right** buttons on the earbuds simultaneously. To power on, press and hold (3 sec) the **Left** or **Right** buttons to power on each earbud individually.

7.2 Music controls for Microsoft Teams earbuds





Left earbud	Function	Right earbud
Press the Left button when not on a call	Play/pause music	
Double-press the Left button when listening to music	Next track	
Triple-press the Left button when listening to music Repeat to skip to the previous track	Restart track or previous track	

Button functions on the left earbud can be reassigned using MyControls in Jabra Sound+.

7.3 Call controls for Microsoft Teams earbuds





Left earbud	Function	Right earbud
	Answer call	Press the Right button
	End/Reject call	Double-press the Right button
	Mute/unmute microphone	Press the Right button

7.4 Microsoft Teams controls for Microsoft Teams earbuds





Left earbud	Function	Right earbud
	Bring Microsoft Teams to foreground on computer	Press the Right button when signed into Microsoft Teams
	Join active Microsoft Teams meeting	Press the Right button when signed into Microsoft Teams
	View Microsoft Teams missed calls and voicemails	Press the Right button when signed into Microsoft Teams
	Raise hand in Microsoft Teams Meeting	Press and hold the Right button for 1 second when signed into Microsoft Teams

7.5 HearThrough, ANC, and Voice assistant controls for Microsoft Teams earbuds





Left earbud	Function	Right earbud
	Cycle between HearThrough and ANC	Double press the Right button when not on a call
Press and hold the Left button for 1 second when not on a call	Activate Voice assistant (Siri, Google Assistant, Amazon Alexa)	

HearThrough, ANC, and voice assistant controls and settings can be customized in Jabra Sound+.

7.6 Music controls for UC earbuds





Left earbud	Function	Right earbud
	Play/pause music	Press the Right button when not on a call
	Volume up	Press and hold the Right button
Press and hold the Left button	Volume down	
	Next track	Double-press the Right button when listening to music
	Restart track or previous	Triple-press the Right button when listening to music
	track	Repeat to skip to the previous track

Button functions can be reassigned using MyControls in Jabra Sound+.

7.7 Call controls for UC earbuds





Left earbud	Function	Right earbud
Press the Left or Right button	Answer call	Press the Left or Right button
Double-press the Left or Right button	End/Reject call	Double-press the Left or Right button
Press the Left or Right button	Mute/unmute microphone	Press the Left or Right button
	Volume up	Press and hold the Right button
Press and hold the Left button	Volume down	

Button functions can be reassigned using MyControls in Jabra Sound+.

7.8 HearThrough and ANC controls for UC earbuds






Left earbud	Function	Right earbud
Press the Left button when not on a call	Cycle between HearThrough and ANC	

HearThrough and ANC controls and settings can be customized in Jabra Sound+.

7.9 Adjustable Active Noise Cancellation (ANC)

Active Noise Cancellation (ANC) counters noise by detecting and analyzing the pattern of incoming sound and then generating an antinoise signal to cancel noise out. As a result, you experience a reduced level of surrounding noise during music.


Adjustable ANC can be configured to your specific hearing profile in Jabra Sound+.



7.10 HearThrough

HearThrough enables you to pay attention to your surroundings and engage in conversation, when not on a call, without the need to remove the earbuds. The microphones pick up surrounding sounds and transmit them to the speakers.


HearThrough can be adjusted in Jabra Sound+.



7.11 Sidetone

Sidetone enables you to hear your own voice when you are on a call. The benefit of Sidetone is that it enables you to determine how loud you are speaking.

Sidetone is on by default during calls and can be turned on/off in Jabra Direct or Jabra Sound+.



By default, Sidetone on/off cannot be controlled using the earbuds. However, it can be added to the earbuds using MyControls in Jabra Sound+.

7.12 Single earbud use for Microsoft Teams earbuds

The right or left earbud can be used individually for music playback or for calls. To activate single earbud mode, place the unused earbud into the charging case.

Left button	Left earbud only	
	Cycle between HearThrough and ANC	Double-press the Left button when not on a call
	Answer call	Press the Left button
	End/Reject call	Double-press the Left button
	Mute/unmute microphone	Press the Left button when on a call
Ser	Bring Microsoft Teams to foreground on computer	Press the Left button when signed into Microsoft Teams
	Join active Microsoft Teams meeting	Press the Left button when signed into Microsoft Teams
	View Microsoft Teams missed calls and voicemails	Press the Left button when signed into Microsoft Teams
	Adjust volume	Use the volume controls on the connected mobile device

Right button	Right earbud on	ly
	Cycle between HearThrough and ANC	Double-press the Right button when not on a call
	Answer call	Press the Right button
	End/Reject call	Double-press the Right button
	Mute/unmute microphone	Press the Right button when on a call
Japan	Bring Microsoft Teams to foreground on computer	Press the Right button when signed into Microsoft Teams
	Join active Microsoft Teams meeting	Press the Right button when signed into Microsoft Teams
	View Microsoft Teams missed calls and voicemails	Press the Right button when signed into Microsoft Teams
	Adjust volume	Use the volume controls on the connected mobile device

7.13 Single earbud use for UC earbuds

The right or left earbud can be used individually for music playback or for calls. To activate single earbud mode, place the unused earbud into the charging case.

Left button	Left earbud only	,
	Cycle between HearThrough and ANC	Press the Left button when listening to music
	Answer call	Press the Left button
	End/Reject call	Double-press the Left button
A Spiro	Mute/unmute microphone	Press the Left button when on a call
	Activate Voice assistant	Double-press the Left button when not on a call
	Adjust volume	Use the volume controls on the connected mobile device

Right button	Right earbud only	
James	Play/pause music	Press the Right button when listening to music
	Answer call	Press the Right button
	End/Reject call	Double-press the Right button
	Mute/unmute microphone	Press the Right button when on a call
	Next track	Double-press the Right button when listening to music
	Restart track or previous track	Triple-press the Right button when listening to music
		Repeat to skip to the previous track
	Adjust volume	Use the volume controls on the connected mobile device


The left and right earbuds will automatically relink when both earbuds are placed in your ears or in the charging case.

7.14 Auto-pause music

When auto-pause music is enabled in Jabra Director Jabra Sound+, music will automatically pause when one of the earbuds is removed from your ear.

To automatically resume the music, return the earbud to your ear within 60 seconds. After 60 seconds, the music can be manually resumed by pressing the play/pause button.

Auto-pause music is on by default.



7.15 Auto-mute microphone during calls

When auto-mute microphone is enabled in Jabra Direct or Jabra Sound+, the microphone will be automatically muted during a call when one of the earbuds is removed from your ear.

To unmute the microphone, return the earbud to your ear within 60 seconds. After 60 seconds, the microphone can be unmuted by pressing the mute microphone button on the earbud.


Auto-mute microphone is off by default.

7.16 Sleep mode

To conserve battery, the earbuds will automatically power off when they are out of range of your mobile device for 15 minutes and are not in the charging case, or when they have been inactive for 30 minutes.

To exit sleep mode, press and hold (1 sec) the button on each earbud. Alternatively, place the earbuds in the charging case and then remove them from the charging case.

The length of time before the headset enters sleep mode can be adjusted in Jabra Direct or Jabra Sound+.



7.17 MyControls

MyControls is a feature in Jabra Sound+ that enables you to reassign the button controls for the earbuds, offering you the flexibility to configure the controls to your personal preference.

Microsoft Teams controls cannot be changed.

7.18 Multipoint and multiple call handling

The earbuds can accept and handle multiple calls, even on two different connected devices.

	Multiple call handling	
(latting)	End current call and answer incoming call	Press the Right button. Double-press the Right button to end the new call
	Reject incoming call, when on a call	Double-press the Right button

7.19 Voice assistant

Left button Voice assistant



Activate Siri, Google Assistant, Amazon Alexa (device dependent) For UC earbuds, doublepress the **Left** button when not on a call

For Microsoft earbuds, press and hold the **Left** button for 1 second when not on a call

Voice assistant settings and controls can be configured in Jabra Sound+.

7.20 Voice guidance and languages

Voice guidance can be turned on/off and the language can be changed in Jabra Direct or Jabra Sound+.

The following languages are available: English, French, German, Japanese, Mandarin Chinese, Korean.

7.21 Firmware updates

The Jabra Evolve2 Buds can be updated to the latest firmware version in Jabra Direct or Jabra Sound+. Both applications will notify you when an update is available.

The Jabra Link 380 Bluetooth adapter can be updated using Jabra Direct.

If an error occurs during the firmware update, the LED on the charging case will flash red. To complete the update, connect the charging case to a power supply, remove the earbuds from the charging case and then place the earbuds back in the charging case and close the lid. The firmware update will restart.

7.22 Reset the earbuds

Resetting the earbuds clears the list of paired devices and resets all settings.

- 1. Place both earbuds in the charging case.
- Press and hold (10 sec) the Left and Right buttons on the earbuds simultaneously until the LEDs on the earbuds flash pink.
- 3. Close the lid of the charging case for 5 seconds to complete the reset.

The earbuds will need to be re-paired to your mobile device. Remember to delete/forget the pairing in the Bluetooth menu on your mobile device.

8. Software

8.1 Jabra Direct

Jabra Direct is computer software designed to support, manage and enable optimal functionality for Jabra devices.

Download the latest free version from jabra.com/direct

8.2 Jabra Sound+



9. Support

9.1 FAO


View the FAQs on Jabra.com/help/evolve2buds

9.2 How to care for your earbuds

- Always store the earbuds in the charging case and safely protected.
- To prevent the depletion of the battery lifetime or capacity, avoid storing the earbuds in hot or cold environments, such as a closed car in summer, or in winter conditions.
- It is recommended to store the earbuds between -20°C and 45°C (-4°F and 113°F).
- Do not store the earbuds for extended periods of time without recharging them (max. three months).
- If the earbuds or the charging case become dirty, it is recommended to clean them with a soft, lint-free cloth that has been dampened with clean water.
- The charging case uses the standard USB voltage of 5v +- 0.25v. It is not recommended to charge the earbuds using a power supply with a higher voltage.

9.3 Replacement accessories

Replacement or additional accessories can be purchased online at jabra.com/accessories.



Jabra Link 380 Bluetooth adapter




USB-A to USB-C charging adapter



Wireless charging pad



USB-A charging cable



9.4 Using replacement earbuds

- 1. Place the replacement earbuds into the charging case and close the lid.
- Open the charging case lid and remove the earbuds.
- 3. Wear the earbuds and follow the voice instructions to pair with your mobile device.
- 4. Update the earbud firmware in Jabra Sound+.

9.5 Using a replacement charging case

Before using a replacement charging case for the first time, it will need to be synced with your current earbuds and charged for 1 hour.

To begin syncing, place your current earbuds inside the replacement charging case and close the lid for 10 seconds. If the LED on the charging case flashes pink this indicates that the firmware is being updated. Please wait until the LED stops flashing pink before opening the charging case.

9.6 Using a replacement Jabra Link 380

To connect a replacement Jabra Link 380 with Jabra Evolve2 Buds, plug the Jabra Link 380 into your computer and launch Jabra Direct. Jabra Direct will guide you through the process of connecting the Jabra Link 380 to the Jabra Evolve2 Buds.