



Enforcer™ Dome Security Camera

4K Ultra HD for NVRs

Instruction Manual

1 Introduction

Congratulations on the purchase of your Swann Enforcer™ Dome Security Camera.

- 4K Upscaled Ultra HD video with sensor spotlight plus red & blue flashing lights
- Microphone on camera helps capture extra detail of what's happening at your property
- True Detect™ Heat & Motion sensing for reliable alerts
- Powerful Night2Day™ color night vision
- Works in rain & snow all year round

Important instructions

1. Make sure the camera is fixed correctly and stable if fastened in place.
2. Never place strain of any kind on the network cable connection. It's designed to clip into the Ethernet port, but it won't support weight and can be broken.

3. Do not operate if wires and terminals are exposed.


Important Note: All jurisdictions have specific laws and regulations relating to the use of cameras. Before using any camera for any purpose, it is the buyer's responsibility to be aware of all applicable laws and regulations that limit the use of cameras.


About this Manual: The content in this manual is for information purposes only and is subject to change without notice. While every effort is made to ensure that this manual is accurate at the time of printing, no liability is assumed for any errors occurred.

For instructions on how to configure your camera for motion detection, changing image settings, and other functions available, please consult the manual for your NVR. Go to support.swann.com, search for your model, then download.

2 Connecting the Camera

To connect the camera to your NVR, simply connect the supplied Ethernet cable to the LAN connection on the camera then plug the other end of the cable into one of the camera inputs on the back of your NVR.




 **Please note:** The power connector is provided as an alternative power option if required. Your NVR will provide power over the Ethernet cable when connected and a separate power adapter is not required.


3 Mounting the Camera

The camera can be mounted onto a flat vertical or horizontal surface and must be of sufficient strength to hold the camera.

Step 1: Press the button **(1)** to release the dome enclosure and the dome camera from the mounting bracket.




Step 2: You will see a black cable **(2)** connected to the camera, which in turn is connected to the camera bracket's black cable.



Rotate the seal cap **(3)** clockwise and gently pull apart the connection to disconnect. Remove the dome camera from the camera bracket.

Step 3: Position the mounting bracket in the location you want to mount the dome camera to. Using a pencil or magic marker, mark the mounting holes **(4)** and hole **(5)** for the camera's cable.



Use a hole saw that you can attach to a drill to make a hole for the cable. A large drill bit can also be used.


(continued on next page)

4 Mounting the Camera

Step 4: Using the appropriate screws for the surface you are mounting to, secure the bracket in place. If mounting to a wooden surface, screw the bracket directly to the surface. If mounting to a masonry surface (brick or concrete), you'll need to use the supplied wall plugs.


Step 5: Connect the supplied Ethernet cable to the camera's cable (see **Fitting the Weather Protector** to seal the connection). Reconnect the black cable on the camera to the black cable connected to the bracket. Rotate the seal cap anti-clockwise to tighten.

Sit the dome camera onto the camera bracket (as shown above right), then place the dome enclosure into the camera bracket and lock it in place. The camera can be rotated left or right (rotate the camera bracket left or right as well) or up and down. Check the image on your NVR and make adjustments as necessary.



5 Fitting the Weather Protector

The weather protector provides a weather-resistant shield for the camera's Ethernet connector to prevent damage from moisture, dust, and other external factors that could interfere with the electrical connection. We also recommend you seal the joints with electrical tape to ensure a more weatherproof seal.



1. Place the Rubber-O-ring around the Camera Ethernet Connector.
2. Carefully push the Ethernet Cable through the Seal Cap and then the Seal Tube.
3. Connect the RJ45 Connector on the Ethernet Cable to the Camera Ethernet Connector ensuring the locking tab securely clicks in.
4. Align the lugs inside the Seal Tube to the Camera Ethernet Connector, then rotate the Seal Tube to lock it in place. The Rubber O-ring should become

slightly bulged when the Seal Tube has been correctly connected.

5. Gently open the pre-cut slit of the Foam Weather Seal and wrap it around the Ethernet Cable between the Seal Tube and the Seal Cap. Push this into the Seal Tube until it is almost all the way in.
6. Firmly push the Seal Cap over the end of the Seal Tube and rotate it clockwise to screw it on to the Seal Tube. Continue to tighten until the Foam Weather Seal bulges slightly from the end.

6 Camera Location Tips

1. Take into consideration what you want to monitor and where you'll get the best view of it.
2. How you're going to connect the camera to your monitoring system; remember that cables and connections should be kept out of the weather.
3. How to keep the camera out of harm's way. We recommended mounting your camera at an elevated position.
4. Place your camera as close to the area of interest as practicable. The best position is from about 13ft/4m above looking slightly down, keeping in mind the details you are looking for.
5. Although the sky looks nice when you look at the live view from your camera, it is an unlikely direction for an offender to approach. Make sure your camera has minimal sky in it as the light in daylight can make the foreground of the image darker.
6. Think about the most likely way a potential offender may approach your home, use your camera to give you the best coverage of these areas.
7. The camera's casing is resistant to different weather conditions and tampering. It would take an overwhelming event to damage the housing.
8. The camera is weather and water-resistant but, prolonged exposure to adverse weather conditions such as sunlight and excessive moisture can damage the internal components.
9. Run cables inside a wall cavity or other protected enclosure, and ensure that all wiring and connectors are insulated and protected from moisture.
10. Don't put your cable near live electrical wiring. AC electricity generates radio noise, which can interfere with the signal from your camera.

Helpdesk & Resources

Visit Swann Support Center at support.swann.com. You can register your product for dedicated customer support, download guides, find answers to commonly asked questions, and more.



Product Registration



Customer Support



Product Manuals



Frequently Asked Questions



Support Community

